

ERHARD JUNGHANS



SEIT 1861

Instruments of time.

1861 saw the dawn of a new era in German watch manufacturing, with the visionary and entrepreneur *Erhard Junghans*. Today, for the Erhard Junghans brand "Made in Germany" once again stands for timekeeping instruments of the utmost precision and value-adding functionality with a classic, design-oriented style.

With pioneering spirit and creative energy *Erhard Junghans* breathed new life into traditional values, in the process leaving a permanent impression on the course of time.

Today, as was the case in those days, Schramberg has witnessed the coming together of individuals to produce the exceptional – just as *Erhard Junghans* did in his era.

The same intention. A new beginning.

Contents

General instructions for use

Page

18–19

Operating elements and functions

20–23

General information

24–25

General instructions for use

Winding the watch

In the winding position (crown in Position A) the automatic movement can also be wound by hand. 2-3 turns of the crown suffice to set the movement in motion. It is better to wind the watch completely, as this guarantees maximum accuracy and power reserve (including after removal of the watch). The watch should be worn after winding in order for the automatic winding mechanism to maintain a fully-wound state (via the rotor movement).

Setting the date

Pull the crown to Position B (fast adjustment). The date can be altered by turning the crown to the right. Rotate the crown until the date of the previous day is displayed. (The actual date is then adjusted with the setting of the time).

Important: Date alteration should not be performed between 8 PM and 3 AM, as in this period the date is switched automatically by the movement and damage may be caused to the switching mechanism.

If the month has less than 31 days, the date must be forwarded to the 1st of the following month by hand.

Setting the time

Pull the winding button out into position C. This stops the clockwork. Please make sure that the seconds hand comes to a stop right above the 60th second marker when stopping the clockwork if you would like the time on your watch to be accurate to the second. Now turn the winding button to the left. The date will be updated automatically to the current date when the hour hand passes 12 pm. You can now continue turning the winding button to adjust the time accurately to the minute. Press down the winding button again into position A to start the seconds hand.

Operating elements and functions

Creator Automatic calibre J830

See information in instructions for use

– Winding the watch – Setting the time – Setting the date



1 Hour hand
2 Minute hand
3 Second hand

4 Date
5 Winding button

Technical information calibre J830

Mechanical movement with display for date

Bi-directional automatic winding mechanism with ball bearing

Finishing: "Côtes de Genève" finishing on bridges and rotor, blued screws

28 jewels

28,800 vibrations per hour

Power reserve > 48 hours

Anti-magnetic as per DIN 8309

Spring: Flat spring

Balance wheel: Nickel plated



General information

Water resistance

Your Erhard Junghans watch has been tested for water resistance to a pressure of 3 ATM. This test indicates that your watch is water resistant to splashing and rain. However, the watch should not be worn when showering, bathing, swimming or diving. The 3 ATM water resistance status applies to factory-new watches only. External influences, such as damage to the crown, pushers and glass, may affect water resistance. It is therefore important that you have your watch examined. If moisture has entered the watch, this must be investigated by customer service without delay. Water entering the watch may result in damage. We therefore recommend that you contact an Erhard Junghans specialist retailer.

Strap

Your Erhard Junghans watch is equipped with a high quality reptile leather strap, which has been tested extensively at our company. It should be noted that leather straps are not suitable for wearing in water and should not be subjected to strong UV rays. Please use an original strap if you choose to replace your strap.

Care

Watch and strap can be cleaned with a dry or slightly dampened soft cloth. Note: do not use chemical cleaning agents (e.g. benzine or paint thinners). This may result in damage to the surface.

Service

Service tasks such as repairs to glass, seal or strap should only be performed by specialist retailers. We therefore recommend that you contact an Erhard Junghans specialist retailer.

A partner in your vicinity can be located at www.erhard-junghans.de or we will be happy to name you one on the following telephone number +49.7422 18-888.