



JUNGHANS

GERMANY. SINCE 1861

Quarzwerk
Quartz movement
J640.96

JUNGHANS - DIE DEUTSCHE UHR

ENGLISH	12
FRANÇAIS	20
ESPAÑOL	28
ITALIANO	36
NEDERLANDS	44
DANSK	52
MAGYAR	60
ČESKY	68
SLOVENSKY	76
日本語	84
中文	92
한국의	100

JUNGHANS – THE GERMAN WATCH

Many congratulations on your purchase of a timepiece from Junghans.

What began in 1861 with the founding of the firm in Schramberg quickly developed into one of the most fascinating success stories of the German watchmaking industry. While since that time the demands made of watches may have changed, the Junghans philosophy has always remained the same. Innovative flair and the constant pursuit of precision right down to the smallest detail define how the company works and thinks. You can see and sense this in every watch that carries the Junghans name. For as diverse as the Junghans range may be, it pursues one single goal: to combine traditional craftsmanship with cutting-edge watch technology and exciting design. That makes every watch with the Junghans star unique.

We hope you will enjoy this very special time-keeping instrument.

Yours,
Uhrenfabrik Junghans GmbH & Co. KG


Contents

Controls and functions	15
Setting the time	15
Setting the date	16
Ready for use	16
General information	17
Impermeability	18
Technical information	19

Page

15
15
16
16
17
18
19

Controls and functions



Setting the time

Pull the winder into position C. This stops the movement.

So that you are able to set the watch accurately to the second, it is helpful to stop the movement as the second hand passes 60. Now you can position the minute hand exactly on the minute line and set the desired time.

To start the second hand going again, press the crown back into position A.

Setting the date

Pull the crown into position B. You can now adjust the date by turning the crown to the right. **You must not make any change to the date between 8pm and 2am, as the movement moves it forward automatically during this time and any manual adjustment could damage the switching mechanism.**

If the month has less than 31 days, you have to set the date manually to the first day of the following month.

Ready for use

To ensure that your Junghans watch is always ready for use, you should avoid allowing its power reserves to run down. The watch regularly checks to see if it still has sufficient battery power. If it no longer has enough (e.g. because the battery has run out or the ambient temperature is too low, which impairs battery performance), the second hand stops for 4 seconds and then quickly catches these 4 steps up.

If the battery does not recover (e.g. through the ambient temperature getting better), you should take your watch as soon as possible to your authorised specialist dealer to have the battery changed. Alternatively, send it to the Junghans Service Centre.

Please ensure that the battery is disposed of properly in accordance with statutory regulations.

General information

External influences can affect the watch's waterproof qualities, which may let in moisture. We therefore recommend that you have your watch regularly inspected by your Junghans specialist. Other servicing tasks or wrist strap repairs should also be done by your Junghans specialist. Your watch is fitted with a quality wrist strap that has undergone multiple inspections in our factory. If, however, you decide to change the strap, please fit a new one of the same quality, preferably an original Junghans wrist strap. Watch and wrist strap can be cleaned with a dry or slightly moistened cloth.

NB: Do not use chemical cleaners (e.g. benzine or paint thinners). These may harm the surface.

Declaration of Conformity

Uhrenfabrik Junghans GmbH & Co. KG herewith declares that this product conforms to the principle requirements and other relevant stipulations of Directive 1999/5/EC.

A corresponding declaration of conformity can be requested from info@junghans.de.

Impermeability

Marking	Instructions for use				
	 Washing, rain, splashes	 Shower	 Bath	 Swimming	 Diving without equipment
No mark	No	No	No	No	No
3 ATM	Yes	No	No	No	No
5 ATM	Yes	No	Yes	No	No
10 ATM	Yes	Yes	Yes	Yes	No

The designation "3–10 ATM" only applies to brand new watches. External influences can affect water resistance. Please have your watch checked regularly.

Technical information

- Quartz movement
- 7 jewels
- Frequency 32'768 Hz
- Average life of battery up to 31 months