

Kaliber J880.1

JUNGHANS - DIE DEUTSCHE UHR

JUNGHANS – THE GERMAN WATCH

Many congratulations on your purchase of a timepiece from Junghans.

What began in 1861 with the founding of the firm in Schramberg quickly developed into one of the most fascinating success stories of the German watchmaking industry. While since that time the demands made of watches may have changed, the Junghans philosophy has always remained the same. Innovative flair and the constant pursuit of precision right down to the smallest detail define how the company works and thinks. You can see and sense this in every watch that carries the Junghans name. For as diverse as the Junghans range may be, it pursues one single goal: to combine traditional craftsmanship with cutting-edge watch technology and exciting design. That makes every watch with the Junghans star unique.

We hope you will enjoy this very special time-keeping instrument.

Yours,

Uhrenfabrik Junghans GmbH & Co. KG

Contents

Instructions for use

General information

Page

17

22

Instructions for use Calibre J880.1

Important note:


Do not make any changes to the date between 08:00 p.m. and 02:00 a.m., as the date is automatically advanced by the movement during this period and you could damage the date advance mechanism.

Winding up the watch

With the winder in position A, you can wind up the automatic movement manually. At least 2 to 3 rotations of the winder are needed to start the movement. It is better to wind it up completely. It is fully wound up after c. 40 rotations of the winder, as then the maximum accuracy and its power reserve (even after the watch is put down) will last for the maximum period. If your model has a screw-locked winder, this must be unscrewed by turning it to the left to start your watch going. After you have set your watch, you should wear it, so that the automatic winding system (via rotor movement) keeps it constantly operational.

Features and functions

Calibre J880.1



Setting the time

Pull the winder into position C. That stops the watch movement. To set your watch accurately to the second, it is best to stop the movement as the second hand is passing the figure 60. You can now position the minute hand precisely in line with the relevant minute marker and set the desired time. Press the winder back into position A to start the second hand.

Setting the date and day of week

Pull the winder into position B. You can now set the date by turning it to the right and the day of the week by turning it to the left. **Do not make any changes to the date and day between 08:00 p.m. and 02:00 a.m., as the date and day is automatically advanced by the movement during this period and you could damage the advance mechanism.** If the month has less than 31 days, set the date manually to the first day of the following month.

Using the chronoscope

Starting time measurement:

You start the chronoscope by pressing the start-stop button (10).

Stopping time measurement:

You stop the chronoscope by pressing the start-stop button (10) again.

Reset:

Press the reset button (11). This returns all three of the stopwatch hands to their starting position.

Adding measured times:

After measuring the first time, you can add times together by pressing the start-stop button again instead of the reset button. The chronoscope hands will then continue running from the stopped position.

Technical information

Automatic movement with chronoscope function

Calibre J880.1

Automatic winding mechanism

25 jewels

28,800 semi-vibrations per hour

46 hour power reserve






Anti-magnetic to DIN 8309

Shockproof: Incabloc

Spring: Nivarox II

Balance: Gold-plated nickel

Impermeability

Designation	User Information				
	 Washing, rain, splashes	 Showering	 Bathing	 Swimming	 Diving without equipment
no designation	no	no	no	no	no
3 ATM	yes	no	no	no	no
5 ATM	yes	no	yes	no	no
10 ATM	yes	yes	yes	yes	no

The designation "3–10 ATM" only applies to brand new watches. External influences can affect water resistance. Please have your watch checked regularly.

General information

External influences can affect the watch's waterproof qualities, which may let in moisture. We therefore recommend that you have your watch regularly inspected by your Junghans specialist. Other servicing tasks or wrist strap repairs should also be done by your Junghans specialist. Your watch is fitted with a quality wrist strap that has undergone multiple inspections in our factory. If, however, you decide to change the strap, please fit a new one of the same quality, preferably an original Junghans wrist strap. Watch and wrist strap can be cleaned with a dry or slightly moistened cloth. NB: Do not use chemical cleaners (e.g. benzine or paint thinners). These may harm the surface.